Control Unit

CPU hardware that controls instruction execution

- sends signals to the datapath to operate it
- specifies what operations to perform, what data to move, when to move it, where to move it

Control Signals

Many **control signals** driven by the instruction

```
[  opcode ] [rs][rt][rd][shamt][func] R-type

[  opcode ] [rs][rt][  displacement ] I-type

[  opcode ] [       address         ] J-type
```

Regularity of the MIPS formats

- **opcode** always in bits 31-26 (Op[5-0])
- are always rs & rt
- **base register** always rs
- **branch offset** always bits 15-0

Our R2000 Control Signals

Register file

- register write signal: **RegWrite** asserted for R-type instructions & load
- register destination field: **RegDst** rt, rd
- results value: MemToReg loaded value, R-type instruction result
- all generated by the opcode

ALU

- type of the second operand: ALUSrc register, immediate
- generated by the opcode
- ALU operation: ALUOp add, subtract, and, or, set-on-less-than
    - generated by a small control unit
        - inputs: opcode & func field
        - output: ALU operation
        - examples:
          lw/sw => add
          beq => subtract
          R-type instruction => func value

Our R2000 Control Signals

Memory

- read signal: **MemRead**
- write signal: **MemWrite**
    - both generated by the opcode

Branch control

- new PC value: **PCSrc**

incremented PC, target address

- generated by the opcode AND'd with Zero

Jump control

- new PC value:

incremented PC or target address, jump address

- generated by the opcode

Changing the Implementation

How should you approach a problem in which you had to redesign the implementation to include another instruction?

- What does the instruction do?
- What parts of the datapath does it need?
  - Can it use what is there already?
  - What new logic or registers does it need?
- How is the datapath activated?
  - What control lines does it need
  - Where should the control lines come from?