

Lecture 12: Board Level Serial Com. i²C / SPI

Vikram Iyer

Announcements and reminders

Lab 2 is posted, due 5/8

Deadline extended to Monday

Tip: for scheduling, start with simple tasks

Midterm on 5/12

Next Friday, here (MOR 230) in class

Everything through today

C programming

Number representation and logical operators

Pointers

Schedulers

Interrupts




Last time and plan for today


- Last time
 - Reading analog data and working with the joystick
 - Review context switching
 - Concept of stack
 - Introduction to interrupts
- Today
 - Code examples
 - Communication protocols (I2C, SPI)

How can we send data between chips?

How can we send data between chips?



How can we send data between chips?



SPI: Serial Peripheral Interface


- Purpose: to communicate between ICs on a board with fewer pins and traces.
- Developed by Motorola in 1980's
- Reference: [Wikipedia](#)
- 4-wire, Serial, "data-loop"

Obsolete Name	Replacement Name
Master	Controller
Slave	Peripheral
MISO	POCI
MOSI	PICO
SS	CS



SPI Basic data loop

CONTROLLER



PERIPHERAL




3-Wire SPI



4-Wire SPI




Multiple SPI Devices, Option 1: Chip Select



- + Individual chip access
- - more pins


Multiple SPI Devices, Option 2: Big loop



- + fewer pins
- - slower, all at one time

SPI on our AtMega 2560

Figure 21-1. SPI Block Diagram⁽¹⁾





Example of SPI: Biodegradable mouse



Mouse Operation

I²C (inter-integrated circuit bus)

- Purpose: to communicate between ICs on a board with fewer pins and traces.
- Developed by Philips in 1980's (now NXP)
- Reference: [NXP Documentation](#)
 - The name I²C is proprietary, some chips call this “Two Wire Interface” (TWI)
- 2-wire, Serial, bi-directional
- SCL: clock wire
- SDA: data wire

I²C (inter-integrated circuit bus)


Controller: One device on the I2C bus which controls transmission and supplies the clock signal.

Peripheral: One or more other devices on I2C bus which send and/or receive data.


Obsolete Name	Replacement Name
Master	Controller
Slave	Peripheral

I²C (inter-integrated circuit bus)



- SCL: clock line provided by Controller
- SDA: bi-directional serial data



I²C (inter-integrated circuit bus)



I²C (inter-integrated circuit bus)




Advantage:



- Only requires 4 wires and can connect many devices
- Available on many small chips





I2C “Start Condition” & “Stop Condition”



I2C Protocol



I2C Protocol



I2C Addresses

I2C address is hard coded into the chip but there are only 128 (2^7) of them!

[[Adafruit's List of I2C addrs](#)]

What if you want to use 2 chips with same I2C addr???


I2C Addresses

I2C address is hard coded into the chip but there are only 128 (2^7) of them!


[[Adafruit's List of I2C addr](#)s]

What if you want to use 2 chips with same I2C addr???

Use chip select / enable bits (if available) (driven by random I/O pins)



I2C Protocol



Step 1: Find the registers to read/write from

Addr (Hex)	Addr (Dec.)	Register Name	Serial I/F	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
67	103	I2C_MST_DELAY_CTRL	R/W	DELAY_ES_SHADOW	-	-	I2C_SLV4_DLY_EN	I2C_SLV3_DLY_EN	I2C_SLV2_DLY_EN	I2C_SLV1_DLY_EN	I2C_SLV0_DLY_EN
68	104	SIGNAL_PATH_RESET	R/W	-	-	-	-	-	GYRO_RESET	ACCEL_RESET	TEMP_RESET
6A	106	USER_CTRL	R/W	-	FIFO_EN	I2C_MST_EN	I2C_IF_DIS	-	FIFO_RESET	I2C_MST_RESET	SIG_COND_RESET
6Bj	107	PWR_MGMT_1	R/W	DEVICE_RESET	SLEEP	CYCLE	-	TEMP_DIS	CLKSEL[2:0]		
6C	108	PWR_MGMT_2	R/W	LP_WAKE_CTRL[1:0]		STBY_XA	STBY_YA	STBY_ZA	STBY_XG	STBY_YG	STBY_ZG
72	114	FIFO_COUNTH	R/W	FIFO_COUNT[15:8]							
73	115	FIFO_COUNTL	R/W	FIFO_COUNT[7:0]							
74	116	FIFO_R_W	R/W	FIFO_DATA[7:0]							
75	117	WHO_AM_I	R	-	WHO_AM_I[6:1]						-

4.28 Register 107 – Power Management 1

PWR_MGMT_1

Type: Read/Write

Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
6B	107	DEVICE_RESET	SLEEP	CYCLE	-	TEMP_DIS	CLKSEL[2:0]		



Parameters:

- DEVICE_RESET* When set to 1, this bit resets all internal registers to their default values. The bit automatically clears to 0 once the reset is done. The default values for each register can be found in Section 3.
- SLEEP* When set to 1, this bit puts the MPU-60X0 into sleep mode.
- CYCLE* When this bit is set to 1 and *SLEEP* is disabled, the MPU-60X0 will cycle between sleep mode and waking up to take a single sample of data from active sensors at a rate determined by *LP_WAKE_CTRL* (register 108).
- TEMP_DIS* When set to 1, this bit disables the temperature sensor.
- CLKSEL* 3-bit unsigned value. Specifies the clock source of the device.

Step 1: Find the registers to read/write from

Addr (Hex)	Addr (Dec.)	Register Name	Serial I/F	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
67	103	I2C_MST_DELAY_CTRL	R/W	DELAY_ES_SHADOW	-	-	I2C_SLV4_DLY_EN	I2C_SLV3_DLY_EN	I2C_SLV2_DLY_EN	I2C_SLV1_DLY_EN	I2C_SLV0_DLY_EN
68	104	SIGNAL_PATH_RESET	R/W	-	-	-	-	-	GYRO_RESET	ACCEL_RESET	TEMP_RESET
6A	106	USER_CTRL	R/W	-	FIFO_EN	I2C_MST_EN	I2C_IF_DIS	-	FIFO_RESET	I2C_MST_RESET	SIG_COND_RESET
6Bj	107	PWR_MGMT_1	R/W	DEVICE_RESET	SLEEP	CYCLE	-	TEMP_DIS	CLKSEL[2:0]		
6C	108	PWR_MGMT_2	R/W	LP_WAKE_CTRL[1:0]		STBY_XA	STBY_YA	STBY_ZA	STBY_XG	STBY_YG	STBY_ZG
72	114	FIFO_COUNTH	R/W	FIFO_COUNT[15:8]							
73	115	FIFO_COUNTL	R/W	FIFO_COUNT[7:0]							
74	116	FIFO_R_W	R/W	FIFO_DATA[7:0]							
75	117	WHO_AM_I	R	-	WHO_AM_I[6:1]						-

Step 2: Hardware connections



Step 3: Writing the code

```
#include "Wire.h" // I2C library.

const int MPU_ADDR = 0x68; // I2C
address
int16_t accel_x, accel_y, accel_z;
int16_t gyro_x, gyro_y, gyro_z; // variables for
gyro raw data
int16_t temperature; //
variables for temperature data

uint16_t temp_H
uint16_t temp_L;

void setup() {
  Serial.begin(9600);
  Wire.begin();
  Wire.beginTransmission(MPU_ADDR);
  Wire.write(0x6B);
  Wire.write(0);
  Wire.endTransmission(true);
}
```

Handwritten notes:
 - Wire.begin();: init I2C
 - Wire.beginTransmission(MPU_ADDR);: I2C address
 - Wire.write(0);: write 0 to reg 6B
 - Wire.endTransmission(true);: send a byte of data

```
void loop() {
  Wire.beginTransmission(MPU_ADDR);
  Wire.write(0x41);
  Wire.endTransmission(false);
  Wire.requestFrom(MPU_ADDR, 2, true);
  // Read temperature data
  temp_high = Wire.read();
  temp_low = Wire.read();
  // Convert temperatures to single value
  temperature = temp_high << 8 | temp_low;
  Serial.print("Temp H: "); Serial.println(temp_H, BIN);
  Serial.print("Temp L: "); Serial.println(temp_L, BIN);
  Serial.print("Temp all: ");
  Serial.println(temperature, BIN);

  Serial.print("Temp = ");
  Serial.println(temperature/340.00+36.53);


  // delay
  delay(1000);
}
```

Handwritten notes:
 - Wire.write(0x41);: where to read data from
 - Wire.requestFrom(MPU_ADDR, 2, true);: 2 bytes

I²C on our AtMega 2560

“TWI” = 2-wire interface

Figure 24-9. Overview of the TWI Module



AtMega2560 Software Examples

SPI: <https://github.com/KareemAhmed96/SPI-Configurable-Driver>

I²C/TWI: Arduino AVR library: [“Wire.h”](#)



AtMega2560 Software Examples

SPI & I²C/TWI: “Bit Banging” code

- Assign your own pins to COPI, PICO, SCLK, CS
- Write code to generate the needed transitions.
- + portable, easy to understand(?), works on small chips
- - slow, blocks other code
- Example [github project](#)