

“Open the pod-bay doors, HAL.”

Computer instruction from *2001: A Space Odyssey*

## Machine Instructions

Computers do exactly what we tell them to do. Instructions are the medium for all tasks -- arithmetic, logic, I/O. Though most ISAs have a unique instruction set, the similarities are greater than the differences, justifying our study of the MIPS ISA alone.

© Larry Snyder, 2000 All rights reserved

## Binary Review

Decimal notation represents numbers by their coefficients of powers of 10. Binary expresses numbers using coefficients of powers of 2.

$$\begin{aligned} 321_{10} &= 3 \times 10^2 + 2 \times 10^1 + 1 \times 10^0 \\ &= 300 + 20 + 1 \\ &= 256 + 64 + 1 \\ &= 1 \times 2^8 + 0 \times 2^7 + 1 \times 2^6 + 0 \times 2^5 + 0 \times 2^4 + 0 \times 2^3 + 0 \times 2^2 + 0 \times 2^1 + 1 \times 2^0 \\ &= 10100001 \end{aligned}$$

© Larry Snyder, 2000 All rights reserved

## Binary Facts

- Alternate forms of binary:
  - Octal: symbols 0-7 and is convertible from binary in groups of 3
  - Hexadecimal: 0-9, A,B,C,D,E,F and is convertible from binary in groups of 4

$$101000001_2 = 101\ 000\ 001 = 501_8$$
$$= 1\ 0100\ 0001 = 141_{16}$$

$$1011\ 1010\ 1101 = \text{BAD}$$

### Fast Approximations

$$2^{10} \approx 1,000$$

$$2^{20} \approx 1,000,000$$


$$2^{30} \approx 1,000,000,000$$

$$2^{40} \approx 1,000,000,000,000$$

© Larry Snyder, 2000 All rights reserved

## Memory Structure


- Computers have two basic types of memory:
  - Random Access Memory (RAM) for storing data and programs while they are being executed
  - Permanent memory for keeping programs and data when they are not be computed upon
    - Hard disks, floppy disks, CDROM, magnetic tape ...
- RAM is one continuous sequence of bytes (8-bit units) each having a consecutive address



© Larry Snyder, 2000 All rights reserved

## Instruction Interpretation

- A computer is a hardware interpretation of the “fetch/execute” cycle



© Larry Snyder, 2000 All rights reserved

## Translating Instructions

- The instructions must have a form understandable to the follower. Computers only understand binary, so translations are needed to lower the level.

Programming Language Instruction (C)

```
i = i + 1;
```

Compiler

Assembly Language Instruction (MIPS)

```
addi $8, $8, 1
```


Assembler

Machine Language Instruction (MIPS ISA)

```
0010 0001 0000 1000 0000 0000 0001
```

© Larry Snyder, 2000 All rights reserved

## Components of Instruction Execution



© Larry Snyder, 2000 All rights reserved

## Anatomy of an Instruction

### Operator and operands

- Operation -- assembly language uses prefix
- Operands separated by commas
- Comments follow #

```
add $8, $9, $10 # Reg8 = Reg9 + Reg10
```

- ISAs usually use a few instruction formats, each format customized to a particular type of instruction

© Larry Snyder, 2000 All rights reserved

## R type Instruction Format

- “R” Type Instructions have all operands in registers
  - There are exactly 3 operands
  - Operands can only be register names
  - Values of operands are integers, with the default being signed integers


```

Reg7 = (Reg8-Reg9) + (Reg6-Reg5)
becomes
sub $10, $8, $9
sub $11, $6, $5
add $7, $10, $11
    
```

© Larry Snyder, 2000 All rights reserved

## Encoding R-type Instructions

- All MIPS instructions are 1 word (4 bytes, 32 bits) long
- Partition word into fixed length fields
  - op = operation
  - rs = first source operand
  - rd = destination operand
  - shamt = shift amount
  - rt = second source operand
  - funct = function field



© Larry Snyder, 2000 All rights reserved