

The Hardware/Software Interface

CSE351 Winter 2013

Procedures and Stacks II

x86-64 Procedure Calling Convention

- Doubling of registers makes us less dependent on stack
 - Store argument in registers
 - Store temporary variables in registers

- What do we do if we have too many arguments or too many temporary variables?

Winter 2013

Procedures and Stacks II

2

x86-64 64-bit Registers: Usage Conventions

<code>%rax</code>	Return value	<code>%r8</code>	Argument #5
<code>%rbx</code>	Callee saved	<code>%r9</code>	Argument #6
<code>%rcx</code>	Argument #4	<code>%r10</code>	Caller saved
<code>%rdx</code>	Argument #3	<code>%r11</code>	Caller Saved
<code>%rsi</code>	Argument #2	<code>%r12</code>	Callee saved
<code>%rdi</code>	Argument #1	<code>%r13</code>	Callee saved
<code>%rsp</code>	Stack pointer	<code>%r14</code>	Callee saved
<code>%rbp</code>	Callee saved	<code>%r15</code>	Callee saved

Winter 2013

Procedures and Stacks II

3

Revisiting swap, IA32 vs. x86-64 versions

```

swap:
    pushl %ebp
    movl %esp, %ebp
    pushl %ebx
    } Set Up

    movl 12(%ebp), %ecx
    movl 8(%ebp), %edx
    movl (%ecx), %eax
    movl (%edx), %ebx
    movl %eax, (%edx)
    movl %ebx, (%ecx)
    } Body

    movl -4(%ebp), %ebx
    movl %ebp, %esp
    popl %ebp
    ret
    } Finish
  
```

```

swap (64-bit long ints):
    movq (%rdi), %rdx
    movq (%rsi), %rax
    movq %rax, (%rdi)
    movq %rdx, (%rsi)
    ret
  
```

- Operands passed in registers
 - First (`xp`) in `%rdi`,
 - second (`yp`) in `%rsi`
 - 64-bit pointers
- No stack operations required (except `ret`)
- Avoiding stack
 - Can hold all local information in registers

Winter 2013

Procedures and Stacks II

4

X86-64 procedure call highlights

- **Arguments (up to first 6) in registers**
 - Faster to get these values from registers than from stack in memory
- **Local variables also in registers (if there is room)**
- **callq instruction stores 64-bit return address on stack**
 - Address pushed onto stack, decrementing %rsp by 8
- **No frame pointer**
 - All references to stack frame made relative to %rsp; eliminates need to update %ebp/%rbp, which is now available for general-purpose use
- **Functions can access memory up to 128 bytes beyond %rsp: the “red zone”**
 - Can store some temps on stack without altering %rsp
- **Registers still designated “caller-saved” or “callee-saved”**


x86-64 Stack Frames

- **Often (ideally), x86-64 functions need no stack frame at all**
 - Just a return address is pushed onto the stack when a function call is made
- **A function *does* need a stack frame when it:**
 - Has too many local variables to hold in registers
 - Has local variables that are arrays or structs
 - Uses the address-of operator (&) to compute the address of a local variable
 - Calls another function that takes more than six arguments
 - Needs to save the state of callee-save registers before modifying them

Example

```
long int call_proc()
{
    long x1 = 1;
    int x2 = 2;
    short x3 = 3;
    char x4 = 4;
    proc(x1, &x1, x2, &x2,
         x3, &x3, x4, &x4);
    return (x1+x2)*(x3-x4);
}
```

```
call_proc:
    subq $32,%rsp
    movq $1,16(%rsp)
    movl $2,24(%rsp)
    movw $3,28(%rsp)
    movb $4,31(%rsp)
    . . .
```




NB: Details may vary depending on compiler.

Example

```
long int call_proc()
{
    long x1 = 1;
    int x2 = 2;
    short x3 = 3;
    char x4 = 4;
    proc(x1, &x1, x2, &x2,
         x3, &x3, x4, &x4);
    return (x1+x2)*(x3-x4);
}
```


```
call_proc:
    subq $32,%rsp
    movq $1,16(%rsp)
    movl $2,24(%rsp)
    movw $3,28(%rsp)
    movb $4,31(%rsp)
    . . .
```



Example

```
long int call_proc()
{
    long x1 = 1;
    int x2 = 2;
    short x3 = 3;
    char x4 = 4;
    proc(x1, &x1, x2, &x2,
         x3, &x3, x4, &x4);
    return (x1+x2)*(x3-x4);
}
```

```
call_proc:
    . . .
    leaq 24(%rsp),%rcx
    leaq 16(%rsp),%rsi
    leaq 31(%rsp),%rax
    movq %rax,8(%rsp)
    movl $4,(%rsp)
    leaq 28(%rsp),%r9
    movl $3,%r8d
    movl $2,%edx
    movq $1,%rdi
    call proc
    . . .
```




Arguments passed in (in order): rdi, rsi, rdx, rcx, r8, r9
← %rsp

Example

```
long int call_proc()
{
    long x1 = 1;
    int x2 = 2;
    short x3 = 3;
    char x4 = 4;
    proc(x1, &x1, x2, &x2,
         x3, &x3, x4, &x4);
    return (x1+x2)*(x3-x4);
}
```

```
call_proc:
    . . .
    leaq 24(%rsp),%rcx
    leaq 16(%rsp),%rsi
    leaq 31(%rsp),%rax
    movq %rax,8(%rsp)
    movl $4,(%rsp)
    leaq 28(%rsp),%r9
    movl $3,%r8d
    movl $2,%edx
    movq $1,%rdi
    call proc
    . . .
```




← %rsp

Example

```
long int call_proc()
{
    long x1 = 1;
    int x2 = 2;
    short x3 = 3;
    char x4 = 4;
    proc(x1, &x1, x2, &x2,
         x3, &x3, x4, &x4);
    return (x1+x2)*(x3-x4);
}
```

```
call_proc:
    . . .
    movswl 28(%rsp),%eax
    movsbl 31(%rsp),%edx
    subl %edx,%eax
    cltq
    movslq 24(%rsp),%rdx
    addq 16(%rsp),%rdx
    imulq %rdx,%rax
    addq $32,%rsp
    ret
```




← %rsp

Example

```
long int call_proc()
{
    long x1 = 1;
    int x2 = 2;
    short x3 = 3;
    char x4 = 4;
    proc(x1, &x1, x2, &x2,
         x3, &x3, x4, &x4);
    return (x1+x2)*(x3-x4);
}
```

```
call_proc:
    . . .
    movswl 28(%rsp),%eax
    movsbl 31(%rsp),%edx
    subl %edx,%eax
    cltq
    movslq 24(%rsp),%rdx
    addq 16(%rsp),%rdx
    imulq %rdx,%rax
    addq $32,%rsp
    ret
```



← %rsp

x86-64 Procedure Summary

- **Heavy use of registers (faster than using stack in memory)**
 - Parameter passing
 - More temporaries since more registers

- **Minimal use of stack**
 - Sometimes none
 - When needed, allocate/deallocate entire frame at once
 - No more frame pointer: address relative to stack pointer

- **More room for compiler optimizations**
 - Prefer to store data in registers rather than memory
 - Minimize modifications to stack pointer