

Memory, Data, & Addressing I

CSE 351 Autumn 2018

Instructor:

Justin Hsia

Teaching Assistants:

Akshat Aggarwal

An Wang

Andrew Hu

Brian Dai

Britt Henderson

James Shin


Kevin Bi

Kory Watson

Riley Germundson

Sophie Tian

Teagan Horkan



<http://xkcd.com/953/>

Administrivia



- ❖ Pre-Course Survey due tonight @ 11:59 pm
- ❖ Lab 0 due Monday (10/1)
- ❖ Homework 1 due Wednesday (10/3)

- ❖ All course materials can be found on the website schedule

- ❖ Make sure you're also enrolled in CSE391 (EEs included)

TA Office Hours

- ❖ CSE 2nd floor breakout
 - Up the stairs in the CSE Atrium (next to the café)
 - At the top of that first flight, the open area with the whiteboard wall is the 2nd floor breakout!



Roadmap

C:

```
car *c = malloc(sizeof(car));
c->miles = 100;
c->gals = 17;
float mpg = get_mpg(c);
free(c);
```

Java:

```
Car c = new Car();
c.setMiles(100);
c.setGals(17);
float mpg =
    c.getMPG();
```

Memory & data

- Integers & floats
- x86 assembly
- Procedures & stacks
- Executables
- Arrays & structs
- Memory & caches
- Processes
- Virtual memory
- Memory allocation
- Java vs. C

Assembly language:

```
get_mpg:
    pushq    %rbp
    movq    %rsp, %rbp
    ...
    popq    %rbp
    ret
```


Machine code:

```
0111010000011000
100011010000010000000010
1000100111000010
110000011111101000011111
```


OS:




Computer system:





Hardware: Physical View



Hardware: Logical View



Hardware: 351 View (version 0)




- ❖ The CPU **executes** instructions
- ❖ Memory **stores** data
- ❖ Binary encoding!
 - Instructions *are* just data

How are data
and instructions
represented?

Binary Encoding Additional Details


- ❖ Because storage is finite in reality, everything is stored as “fixed” length
 - Data is moved and manipulated in fixed-length chunks
 - Multiple fixed lengths (*e.g.* 1 byte, 4 bytes, 8 bytes)
 - Leading zeros now *must* be included up to “fill out” the fixed length
- ❖ Example: the “eight-bit” representation of the number 4 is 0b00000100
 - Most Significant Bit (MSB)
 - Least Significant Bit (LSB)

Hardware: 351 View (version 0)




- ❖ To execute an instruction, the CPU must:
 - 1) Fetch the instruction
 - 2) (if applicable) Fetch data needed by the instruction
 - 3) Perform the specified computation
 - 4) (if applicable) Write the result back to memory

Hardware: 351 View (version 1)



- ❖ More CPU details:
 - Instructions are held temporarily in the **instruction cache**
 - Other data are held temporarily in **registers**
- ❖ **Instruction fetching** is hardware-controlled
- ❖ **Data movement** is programmer-controlled (assembly)


Hardware: 351 View (version 1)



- ❖ We will start by learning about Memory

How does a program find its data in memory?

Byte-Oriented Memory Organization



- ❖ Conceptually, memory is a single, large array of bytes, each with a unique *address* (index)
 - Each address is just a number represented in *fixed-length* binary
- ❖ Programs refer to bytes in memory by their *addresses*
 - Domain of possible addresses = *address space*
 - We can store addresses as data to “remember” where other data is in memory
- ❖ But not all values fit in a single byte... (e.g. 351)
 - Many operations actually use multi-byte values

Peer Instruction Question

- ❖ If we choose to use 4-bit addresses, how big is our address space?
 - *i.e.* How much space can we “refer to” using our addresses?
 - Vote at <http://PollEv.com/justinh>


- A. 16 bits
- B. 16 bytes
- C. 4 bits
- D. 4 bytes
- E. We're lost...

Machine “Words”

- ❖ Instructions encoded into machine code (0’s and 1’s)
 - Historically (still true in some assembly languages), all instructions were exactly the size of a **word**
- ❖ We have *chosen* to tie word size to address size/width
 - word size = address size = register size
 - word size = w bits $\rightarrow 2^w$ addresses
- ❖ Current x86 systems use **64-bit (8-byte) words**
 - Potential address space: 2^{64} addresses
 2^{64} bytes \approx **1.8 x 10¹⁹ bytes**
= 18 billion billion bytes = 18 EB (exabytes)
 - Actual physical address space: **48 bits**


Word-Oriented Memory Organization

- ❖ Addresses still specify locations of *bytes* in memory
 - Addresses of successive words differ by word size (in bytes): *e.g.* 4 (32-bit) or 8 (64-bit)
 - Address of word 0, 1, ... 10?




Word-Oriented Memory Organization

- ❖ Addresses still specify locations of *bytes* in memory
 - Addresses of successive words differ by word size (in bytes): *e.g.* 4 (32-bit) or 8 (64-bit)
 - Address of word 0, 1, ... 10?
- ❖ **Address of word** = address of *first* byte in word
 - The address of *any* chunk of memory is given by the address of the first byte
 - **Alignment**




A Picture of Memory (64-bit view)

- ❖ A “64-bit (8-byte) word-aligned” view of memory:
 - In this type of picture, each row is composed of 8 bytes
 - Each cell is a byte
 - A 64-bit pointer will fit on one row



A Picture of Memory (64-bit view)

- ❖ A “64-bit (8-byte) word-aligned” view of memory:
 - In this type of picture, each row is composed of 8 bytes
 - Each cell is a byte
 - A 64-bit pointer will fit on one row



Addresses and Pointers

64-bit example
(pointers are 64-bits wide)


big-endian

- ❖ An *address* is a location in memory
- ❖ A *pointer* is a data object that holds an address
 - Address can point to *any* data

❖ Value 504 stored at address **0x08**

- $504_{10} = 1F8_{16}$
= 0x 00 ... 00 01 F8

❖ Pointer stored at **0x38** points to address **0x08**




Addresses and Pointers

64-bit example
(pointers are 64-bits wide)

big-endian

- ❖ An *address* is a location in memory
- ❖ A *pointer* is a data object that holds an address
 - Address can point to *any* data
- ❖ Pointer stored at **0x48** points to address **0x38**
 - Pointer to a pointer!
- ❖ Is the data stored at **0x08** a pointer?
 - Could be, depending on how you use it



Data Representations

❖ Sizes of data types (in bytes)

Java Data Type	C Data Type	32-bit (old)	x86-64
boolean	bool	1	1
byte	char	1	1
char		2	2
short	short int	2	2
int	int	4	4
float	float	4	4
	long int	4	8
double	double	8	8
long	long	8	8
	long double	8	16
(reference)	pointer *	4	8

address size = word size

To use "bool" in C, you must `#include <stdbool.h>`

Memory Alignment

- ❖ **Aligned:** Primitive object of K bytes must have an address that is a multiple of K
 - More about alignment later in the course

K	Type
1	char
2	short
4	int, float
8	long, double, pointers



- ❖ For good memory system performance, Intel (x86) recommends data be aligned
 - However the x86-64 hardware will work correctly otherwise
 - Design choice: x86-64 instructions are *variable* bytes long

Byte Ordering

- ❖ How should bytes within a word be ordered *in memory*?
 - **Example:** store the 4-byte (32-bit) `int`:
0x a1 b2 c3 d4
- ❖ By convention, ordering of bytes called *endianness*
 - The two options are **big-endian** and **little-endian**
 - In which address does the least significant *byte* go?
 - Based on *Gulliver's Travels*: tribes cut eggs on different sides (big, little)

Byte Ordering


- ❖ Big-endian (SPARC, z/Architecture)
 - Least significant byte has highest address
- ❖ Little-endian (x86, x86-64)
 - Least significant byte has lowest address
- ❖ Bi-endian (ARM, PowerPC)
 - Endianness can be specified as big or little
- ❖ **Example:** 4-byte data 0xa1b2c3d4 at address 0x100




Byte Ordering Examples

Decimal:	12345
Binary:	0011 0000 0011 1001
Hex:	3 0 3 9

```
int x = 12345;
// or x = 0x3039;
```



```
long int y = 12345;
// or y = 0x3039;
```



(A long int is the size of a word)

Peer Instruction Question:

- ❖ We store the value $0x\ 01\ 02\ 03\ 04$ as a **word** at address $0x100$ in a big-endian, 64-bit machine
 - ❖ What is the **byte of data** stored at address $0x104$?
 - Vote at <http://PollEv.com/justinh>
-
- A. **0x04**
 - B. **0x40**
 - C. **0x01**
 - D. **0x10**
 - E. **We're lost...**

Endianness

- ❖ *Endianness only applies to memory storage*
- ❖ Often programmer can ignore endianness because it is handled for you
 - Bytes wired into correct place when reading or storing from memory (hardware)
 - Compiler and assembler generate correct behavior (software)
- ❖ Endianness still shows up:
 - Logical issues: accessing different amount of data than how you stored it (e.g. store `int`, access byte as a `char`)
 - Need to know exact values to debug memory errors
 - Manual translation to and from machine code (in 351)

Summary

- ❖ Memory is a long, *byte-addressed* array
 - Word size bounds the size of the *address space* and memory
 - Different data types use different number of bytes
 - Address of chunk of memory given by address of lowest byte in chunk
 - Object of K bytes is *aligned* if it has an address that is a multiple of K
- ❖ Pointers are data objects that hold addresses
- ❖ Endianness determines memory storage order for multi-byte data