

x86-64 Programming I

CSE 351 Spring 2019

Instructor:

Ruth Anderson

Teaching Assistants:

Gavin Cai

Jack Eggleston

John Feltrup

Britt Henderson

Richard Jiang

Jack Skalitzky


Sophie Tian

Connie Wang

Sam Wolfson

Casey Xing

Chin Yeoh



<http://www.smbc-comics.com/?id=2999>

Administrivia

- ❖ Lab 1b due Monday (4/22)
 - Submit `bits.c` and `lab1Breflect.txt`
- ❖ Homework 2 due Wednesday (4/24)
 - On Integers, Floating Point, and x86-64
- ❖ Lab 2 (x86-64) coming soon, due Wednesday (5/01)


Non-Compiling Code

- ❖ You get a zero on the assignment
 - No excuses – you have access to our grading environment

Writing Assembly Code? In 2019???

- ❖ Chances are, you'll never write a program in assembly, but understanding assembly is the key to the machine-level execution model:
 - Behavior of programs in the presence of bugs
 - When high-level language model breaks down
 - Tuning program performance
 - Understand optimizations done/not done by the compiler
 - Understanding sources of program inefficiency
 - Implementing systems software
 - What are the “states” of processes that the OS must manage
 - Using special units (timers, I/O co-processors, etc.) inside processor!
 - Fighting malicious software
 - Distributed software is in binary form

Assembly Programmer's View



❖ Programmer-visible state

- PC: the Program Counter (`%rip` in x86-64)
 - Address of next instruction
- Named registers
 - Together in “register file”
 - Heavily used program data
- Condition codes
 - Store status information about most recent arithmetic operation
 - Used for conditional branching

❖ Memory

- Byte-addressable array
- Code and user data
- Includes *the Stack* (for supporting procedures)

x86-64 Assembly “Data Types”

- ❖ Integral data of 1, 2, 4, or 8 bytes
 - Data values
 - Addresses
 - ❖ Floating point data of 4, 8, 10 or 2x8 or 4x4 or 8x2
 - Different registers for those (e.g. `%xmm1`, `%ymm2`)
 - Come from *extensions to x86* (SSE, AVX, ...)
 - ❖ No aggregate types such as arrays or structures
 - Just contiguously allocated bytes in memory
 - ❖ Two common syntaxes
 - “AT&T”: used by our course, slides, textbook, gnu tools, ...
 - “Intel”: used by Intel documentation, Intel tools, ...
 - Must know which you’re reading
- } Not covered
In 351

What is a Register?

- ❖ A location in the CPU that stores a small amount of data, which can be accessed very quickly (once every clock cycle)
- ❖ Registers have *names*, not *addresses*
 - In assembly, they start with `%` (e.g. `%rsi`)
- ❖ Registers are at the heart of assembly programming
 - They are a precious commodity in all architectures, but *especially* x86


x86-64 Integer Registers – 64 bits wide

<code>%rax</code>	<code>%eax</code>
<code>%rbx</code>	<code>%ebx</code>
<code>%rcx</code>	<code>%ecx</code>
<code>%rdx</code>	<code>%edx</code>
<code>%rsi</code>	<code>%esi</code>
<code>%rdi</code>	<code>%edi</code>
<code>%rsp</code>	<code>%esp</code>
<code>%rbp</code>	<code>%ebp</code>

<code>%r8</code>	<code>%r8d</code>
<code>%r9</code>	<code>%r9d</code>
<code>%r10</code>	<code>%r10d</code>
<code>%r11</code>	<code>%r11d</code>
<code>%r12</code>	<code>%r12d</code>
<code>%r13</code>	<code>%r13d</code>
<code>%r14</code>	<code>%r14d</code>
<code>%r15</code>	<code>%r15d</code>

- Can reference low-order 4 bytes (also low-order 2 & 1 bytes)

Some History: IA32 Registers – 32 bits wide



Memory

- ❖ Addresses
 - `0x7FFFD024C3DC`
- ❖ Big
 - `~ 8 GiB`
- ❖ Slow
 - `~50-100 ns`
- ❖ Dynamic
 - Can “grow” as needed while program runs

vs. Registers

- vs. Names
 - `%rdi`
- vs. Small
 - `(16 x 8 B) = 128 B`
- vs. Fast
 - sub-nanosecond timescale
- vs. Static
 - fixed number in hardware

Three Basic Kinds of Instructions

1) Transfer data between memory and register

- *Load* data from memory into register
 - `%reg = Mem[address]`
- *Store* register data into memory
 - `Mem[address] = %reg`

Remember: Memory is indexed just like an array of bytes!

2) Perform arithmetic operation on register or memory data

- `c = a + b;` `z = x << y;` `i = h & g;`

3) Control flow: what instruction to execute next

- Unconditional jumps to/from procedures
- Conditional branches

Operand types

- ❖ **Immediate:** Constant integer data
 - Examples: `$0x400`, `$-533`
 - Like C literal, but prefixed with ``$'`
 - Encoded with 1, 2, 4, or 8 bytes *depending on the instruction*
- ❖ **Register:** 1 of 16 integer registers
 - Examples: `%rax`, `%r13`
 - But `%rsp` reserved for special use
 - Others have special uses for particular instructions
- ❖ **Memory:** Consecutive bytes of memory at a computed address
 - Simplest example: `(%rax)`
 - Various other “address modes”

`%rax``%rcx``%rdx``%rbx``%rsi``%rdi``%rsp``%rbp``%rN`

x86-64 Introduction

- ❖ Data transfer instruction (`mov`)
- ❖ Arithmetic operations
- ❖ Memory addressing modes
 - `swap` example
- ❖ Address computation instruction (`lea`)

Moving Data

- ❖ General form: `mov_ source, destination`
 - Missing letter (`_`) specifies size of operands
 - Note that due to backwards-compatible support for 8086 programs (16-bit machines!), “word” means 16 bits = 2 bytes in x86 instruction names
 - Lots of these in typical code
- ❖ `movb src, dst`
 - Move 1-byte “**byte**”
- ❖ `movw src, dst`
 - Move 2-byte “**word**”
- ❖ `movl src, dst`
 - Move 4-byte “**long word**”
- ❖ `movq src, dst`
 - Move 8-byte “**quad word**”

movq Operand Combinations

	Source	Dest	Src, Dest	C Analog
movq	Imm	Reg	movq \$0x4, %rax	var_a = 0x4;
		Mem	movq \$-147, (%rax)	*p_a = -147;
	Reg	Reg	movq %rax, %rdx	var_d = var_a;
		Mem	movq %rax, (%rdx)	*p_d = var_a;
	Mem	Reg	movq (%rax), %rdx	var_d = *p_a;

❖ *Cannot do memory-memory transfer with a single instruction*

- How would you do it?

Some Arithmetic Operations

❖ Binary (two-operand) Instructions:

- **Maximum of one memory operand**

- Beware argument order!

- No distinction between signed and unsigned
 - Only arithmetic vs. logical shifts

- How do you implement “ $r3 = r1 + r2$ ”?

Format	Computation	
<code>addq src, dst</code>	$dst = dst + src$	($dst += src$)
<code>subq src, dst</code>	$dst = dst - src$	
<code>imulq src, dst</code>	$dst = dst * src$	signed mult
<code>sarq src, dst</code>	$dst = dst \gg src$	Arithmetic
<code>shrq src, dst</code>	$dst = dst \gg src$	Logical
<code>shlq src, dst</code>	$dst = dst \ll src$	(same as <code>salq</code>)
<code>xorq src, dst</code>	$dst = dst \wedge src$	
<code>andq src, dst</code>	$dst = dst \& src$	
<code>orq src, dst</code>	$dst = dst src$	

↑ operand size specifier

Some Arithmetic Operations

❖ Unary (one-operand) Instructions:

Format	Computation	
incq <i>dst</i>	$dst = dst + 1$	increment
decq <i>dst</i>	$dst = dst - 1$	decrement
negq <i>dst</i>	$dst = -dst$	negate
notq <i>dst</i>	$dst = \sim dst$	bitwise complement

- ❖ See CSPP Section 3.5.5 for more instructions:
`mulq`, `cqto`, `idivq`, `divq`

Arithmetic Example

```
long simple_arith(long x, long y)
{
    long t1 = x + y;
    long t2 = t1 * 3;
    return t2;
}
```

Register	Use(s)
%rdi	1 st argument (x)
%rsi	2 nd argument (y)
%rax	return value

```
y += x;
y *= 3;
long r = y;
return r;
```

```
simple_arith:
    addq    %rdi, %rsi
    imulq   $3, %rsi
    movq    %rsi, %rax
    ret
```

Example of Basic Addressing Modes


```
void swap(long *xp, long *yp)
{
    long t0 = *xp;
    long t1 = *yp;
    *xp = t1;
    *yp = t0;
}
```

```
swap:
    movq    (%rdi), %rax
    movq    (%rsi), %rdx
    movq    %rdx, (%rdi)
    movq    %rax, (%rsi)
    ret
```

Understanding swap ()

```
void swap(long *xp, long *yp)
{
    long t0 = *xp;
    long t1 = *yp;
    *xp = t1;
    *yp = t0;
}
```

```
swap:
    movq    (%rdi), %rax
    movq    (%rsi), %rdx
    movq    %rdx, (%rdi)
    movq    %rax, (%rsi)
    ret
```



<u>Register</u>		<u>Variable</u>
%rdi	↔	xp
%rsi	↔	yp
%rax	↔	t0
%rdx	↔	t1

Understanding swap ()

Registers

<code>%rdi</code>	<code>0x120</code>
<code>%rsi</code>	<code>0x100</code>
<code>%rax</code>	
<code>%rdx</code>	

Memory

	Word Address
123	0x120
	0x118
	0x110
	0x108
456	0x100


swap:

```

movq    (%rdi), %rax    # t0 = *xp
movq    (%rsi), %rdx    # t1 = *yp
movq    %rdx, (%rdi)    # *xp = t1
movq    %rax, (%rsi)    # *yp = t0
ret

```


Understanding swap ()



```
swap:
```

```
    movq    (%rdi), %rax    # t0 = *xp
    movq    (%rsi), %rdx    # t1 = *yp
    movq    %rdx, (%rdi)   # *xp = t1
    movq    %rax, (%rsi)   # *yp = t0
    ret
```

Understanding swap ()




```
swap:
```

```

movq  (%rdi), %rax    # t0 = *xp
movq  (%rsi), %rdx    # t1 = *yp
movq  %rdx, (%rdi)    # *xp = t1
movq  %rax, (%rsi)    # *yp = t0
ret
```


Understanding swap ()



```
swap:
```

```
    movq    (%rdi), %rax    # t0 = *xp
    movq    (%rsi), %rdx    # t1 = *yp
    movq    %rdx, (%rdi)   # *xp = t1
    movq    %rax, (%rsi)   # *yp = t0
    ret
```


Understanding swap ()



swap:

```

movq    (%rdi), %rax    # t0 = *xp
movq    (%rsi), %rdx    # t1 = *yp
movq    %rdx, (%rdi)    # *xp = t1
movq    %rax, (%rsi)    # *yp = t0
ret

```

Memory Addressing Modes: Basic

❖ **Indirect:** (R) $\text{Mem}[\text{Reg}[R]]$

- Data in register R specifies the memory address
- Like pointer dereference in C
- Example: `movq (%rcx), %rax`

❖ **Displacement:** $D (R)$ $\text{Mem}[\text{Reg}[R]+D]$

- Data in register R specifies the *start* of some memory region
- Constant displacement D specifies the offset from that address
- Example: `movq 8(%rbp), %rdx`

Complete Memory Addressing Modes

❖ General:

- $D(Rb, Ri, S) \quad \text{Mem}[\text{Reg}[Rb] + \text{Reg}[Ri] * S + D]$
 - Rb: Base register (any register)
 - Ri: Index register (any register except `%rsp`)
 - S: Scale factor (1, 2, 4, 8) – *why these numbers?*
 - D: Constant displacement value (a.k.a. immediate)

❖ Special cases (see CSPP Figure 3.3 on p.181)

- $D(Rb, Ri) \quad \text{Mem}[\text{Reg}[Rb] + \text{Reg}[Ri] + D] \quad (S=1)$
- $(Rb, Ri, S) \quad \text{Mem}[\text{Reg}[Rb] + \text{Reg}[Ri] * S] \quad (D=0)$
- $(Rb, Ri) \quad \text{Mem}[\text{Reg}[Rb] + \text{Reg}[Ri]] \quad (S=1, D=0)$
- $(, Ri, S) \quad \text{Mem}[\text{Reg}[Ri] * S] \quad (Rb=0, D=0)$

Address Computation Examples

<code>%rdx</code>	0xf000
<code>%rcx</code>	0x0100

$$D(Rb, Ri, S) \rightarrow$$

$$\text{Mem}[\text{Reg}[Rb] + \text{Reg}[Ri] * S + D]$$

Expression	Address Computation	Address
<code>0x8(%rdx)</code>		
<code>(%rdx,%rcx)</code>		
<code>(%rdx,%rcx,4)</code>		
<code>0x80(,%rdx,2)</code>		

Summary

- ❖ There are 3 types of operands in x86-64
 - Immediate, Register, Memory
- ❖ There are 3 types of instructions in x86-64
 - Data transfer, Arithmetic, Control Flow
- ❖ **Memory Addressing Modes:** The addresses used for accessing memory in `MOV` (and other) instructions can be computed in several different ways
 - *Base register, index register, scale factor, and displacement* map well to pointer arithmetic operations