W UNIVERSITY of WASHINGTON

Memory, Data, & Addressing I

CSE 351 Spring 2022

Instructor:

Ruth Anderson

Teaching Assistants:

Melissa Birchfield

Jacob Christy

Alena Dickmann

Kyrie Dowling

Ellis Haker

Maggie Jiang

Diya Joy

Anirudh Kumar

Jim Limprasert

Armin Magness

Hamsa Shankar

Dara Stotland


Jeffery Tian

Assaf Vayner

Tom Wu

Angela Xu

Effie Zheng



http://xkcd.com/953/

Relevant Course Information

- Pre-Course Survey and hw0 due tonight @ 11:59 pm
- hw1 due Friday (4/01) @ 11:59 pm
- Lab 0 due Monday (4/04) @ 11:59 pm
 - This lab is exploratory and looks like a hw; the other labs will look a lot different (involve writing code etc.)
 - Don't worry if everything in Lab 0 doesn't make perfect sense right now!
 We will cover all of these topics in more detail later in the course.
 - Lab 0 is about getting you used to modifying C code and running it to see what the outcome is – a powerful tool for understanding the concepts in this course!
- Readings should be completed by 11am on day of lecture
- Lecture activities should be completed by 11am of NEXT lecture

In-Person Office Hours

Allen breakouts

- Up the stairs in the CSE Atrium (Allen Center, not Gates)
- 2nd, 3rd, 4th, 5th floors

• At the top of the stairs, the open area with the whiteboard wall is the breakout!





Roadmap

C:

car *c = malloc(sizeof(car)); c->miles = 100; c->gals = 17; float mpg = get_mpg(c); free(c);

Java:

Memory & data

Integers & floats
x86 assembly
Procedures & stacks
Executables
Arrays & structs
Memory & caches
Processes
Virtual memory
Memory allocation
Java vs. C

Assembly language:

```
get_mpg:
    pushq %rbp
    movq %rsp, %rbp
    ...
    popq %rbp
    ret
```


OS:

Windows 10 OS X Yosemite

Machine code:

Computer system:









Memory, Data, and Addressing

- Hardware High Level Overview
- Representing information as bits and bytes
 - Memory is a byte-addressable array
 - Machine "word" size = address size = register size
- Organizing and addressing data in memory
 - Endianness ordering bytes in memory
- Manipulating data in memory using C
- Boolean algebra and bit-level manipulations


Hardware: Physical View



Hardware: Logical View



Hardware: 351 View (version 0)




Memory

- The CPU executes instructions
- Memory stores data
- Binary encoding!
 - Instructions are just data


How are data and instructions represented?

Hardware: 351 View (version 0)




- To execute an instruction, the CPU must:
 - 1) Fetch the instruction
 - 2) (if applicable) Fetch data needed by the instruction
 - 3) Perform the specified computation
 - 4) (if applicable) Write the result back to memory

Hardware: 351 View (version 1)



- More CPU details:
 - Instructions are held temporarily in the instruction cache
 - Other data are held temporarily in registers
- Instruction fetching is hardware-controlled
- Data movement is programmer-controlled (assembly)

Hardware: 351 View (version 1)



We will start by learning about Memory

How does a program find its data in memory?

Review Questions

- By looking at the bits stored in memory, I can tell what a particular 4 bytes is being used to represent.
 - A. True B. False
- We can fetch a piece of data from memory as long as we have its address.
 - A. True B. False
- Which of the following bytes have a most-significant bit (MSB) of 1?
 - A. 0x63 B. 0x90
- C. OxCA
- D. OxF


Fixed-Length Binary (Review)

- Because storage is finite in reality, everything is stored as "fixed" length
 - Data is moved and manipulated in fixed-length chunks
 - Multiple fixed lengths (e.g. 1 byte, 4 bytes, 8 bytes)
 - Leading zeros now must be included up to "fill out" the fixed length
- Example: the "eight-bit" representation of the number 4 is 0b00000100

Most Significant Bit (MSB)

Least Significant Bit (LSB)

An Address Refers to a Byte of Memory



- Conceptually, memory is a single, large array of bytes, each with a unique address (index)
 - Each address is just a number represented in fixed-length binary
- Programs refer to bytes in memory by their addresses
 - Domain of possible addresses = address space
 - We can store addresses as data to "remember" where other data is in memory
- But not all values fit in a single byte... (e.g. 351)
 - Many operations actually use multi-byte values

Machine "Words" (Review)

- Instructions encoded into machine code (0's and 1's)
 - Historically (still true in some assembly languages), all instructions were exactly the size of a word
- We have chosen to tie word size to address size/width
 - word size = address size = register size
 - word size = w bits $\rightarrow 2^w$ addresses
- Current x86 systems use 64-bit (8-byte) words
 - Potential address space: 2⁶⁴ addresses
 2⁶⁴ bytes ≈ 1.8 x 10¹⁹ bytes
 = 18 billion billion bytes = 18 EB (exabytes)
 - Actual physical address space: 48 bits

Data Representations


Sizes of data types (in bytes)

Java Data Type	C Data Type	32-bit (old)	x86-64		
boolean	bool	1	1		
byte	char	1	1		
char		2	2		
short	short int	2	2		
int	int	4	4		
float	float	4	4		
	long int	4	8		
double	double	8	8		
long	long long	8	8		
	long double	8	16		
(reference)	pointer *	4	8		

address size = word size


Address of Multibyte Data

- Addresses still specify locations of <u>bytes</u> in memory, but we can choose to *view* memory as a series of <u>chunks</u> of fixed-sized data instead
 - Addresses of successive chunks differ by data size
 - Which byte's address should we use for each word?
- The address of any chunk of memory is given by the address of the first byte
 - To specify a chunk of memory, need both its address and its size




Alignment

- The address of a chunk of memory is considered aligned if its address is a multiple of its size
 - View memory as a series of consecutive chunks of this particular size and see if your chunk doesn't cross a boundary




A Picture of Memory (64-bit view)

- A "64-bit (8-byte) word-aligned" view of memory:
 - In this type of picture, each row is composed of 8 bytes
 - Each cell is a byte
 - An aligned, 64-bit chunk of data will fit on one row



A Picture of Memory (64-bit view)

- A "64-bit (8-byte) word-aligned" view of memory:
 - In this type of picture, each row is composed of 8 bytes
 - Each cell is a byte
 - An aligned, 64-bit chunk of data will fit on one row




Addresses and Pointers

64-bit example (pointers are 64-bits wide)

big-endian

- An address refers to a location in memory
- A pointer is a data object that holds an address
 - Address can point to any data
- Value 504 stored at address 0x08
 - 504₁₀ = 1F8₁₆ = 0x 00 ... 00 01 F8
- Pointer stored at 0x38 points to address 0x08




Addresses and Pointers

64-bit example (pointers are 64-bits wide)

big-endian

- An address refers to a location in memory
- A pointer is a data object that holds an address
 - Address can point to any data
- Pointer stored at 0x48 points to address 0x38
 - Pointer to a pointer!
- Is the data stored at 0x08 a pointer?
 - Could be, depending on how you use it



Byte Ordering (Review)

- How should bytes within a word be ordered in memory?
 - Want to keep consecutive bytes in consecutive addresses
 - Example: store the 4-byte (32-bit) int:

- By convention, ordering of bytes called endianness
 - The two options are big-endian and little-endian
 - In which address does the least significant byte go?
 - Based on *Gulliver's Travels*: tribes cut eggs on different sides (big, little)

Byte Ordering

- Big-endian (SPARC, z/Architecture)
 - Least significant byte has highest address
- Little-endian (x86, x86-64)
 - Least significant byte has lowest address
- Bi-endian (ARM, PowerPC)
 - Endianness can be specified as big or little
- Example: 4-byte data 0xA1B2C3D4 at address 0x100

		0x100	0x101	0x102	0x103	
Big-Endian						
		0x100	0x101	0x102	0x103	
i	 	0,100	0,101	UX102	0,103	
Little-Endian						

Byte Ordering

- Big-endian (SPARC, z/Architecture)
 - Least significant byte has highest address
- Little-endian (x86, x86-64)
 - Least significant byte has lowest address
- Bi-endian (ARM, PowerPC)
 - Endianness can be specified as big or little
- Example: 4-byte data 0xA1B2C3D4 at address 0x100

		0x100	0x101	0x102	0x103	
Big-Endian		A1	B2	C3	D4	
		0.400	0.404	0.400	0.400	
		0x100	0x101	0x102	0x103	
Little-Endian		D4	C3	B2	A1	

Polling Question

- * We store the value $0 \times 01 02 03 04$ as a **word** at address 0×100 in a big-endian, 64-bit machine
- What is the byte of data stored at address 0x104?
 - Vote in Ed Lessons


- A. 0x04
- B. 0x40
- C. 0x01
- D. 0x10
- E. We're lost...

Endianness

- Endianness only applies to memory storage
- Often programmer can ignore endianness because it is handled for you
 - Bytes wired into correct place when reading or storing from memory (hardware)
 - Compiler and assembler generate correct behavior (software)
- Endianness still shows up:
 - Logical issues: accessing different amount of data than how you stored it (e.g. store int, access byte as a char)
 - Need to know exact values to debug memory errors
 - Manual translation to and from machine code (in 351)

Exploration Question

 Assume the state of memory is as shown below for a little-endian machine.



If we (1) read the value of an int at address 0x102, (2) add 8 to it, and then (3) store the new value as an int at address 0x104, which of the following addresses retain their original value?

A. 0x102

B. 0x104

C. 0x105

D. 0x107

Summary

- Memory is a long, byte-addressed array
 - Word size bounds the size of the address space and memory
 - Different data types use different number of bytes
 - Address of chunk of memory given by address of lowest byte in chunk
 - Object of K bytes is aligned if it has an address that is a multiple of K
- Pointers are data objects that hold addresses
- Endianness determines memory storage order for multi-byte data