
Characters, Bits and Addresses

CSE 410, Spring 2004
Computer Systems

<http://www.cs.washington.edu/education/courses/410/04sp/>

Readings and References

- Reading
 - » Sections 3.7 through 3.8, *Computer Organization & Design, Patterson and Hennessy*
 - note error in figure page 149, address 80012 repeated

Beyond Numbers

- Most computers today use 8-bit bytes to represent characters
- How many characters can you represent in an 8-bit byte?
 - » 256
- How many characters are needed to represent all the languages in the world?
 - » a gazillion, approximately

char

- American Standard Code for Information Interchange (ASCII)
 - » published in 1968
 - » defines 7-bit character codes ...
 - » which means only the first 128 characters
 - » after that, it's all “extensions” and “code pages”
- ISO 8859-x
 - » codify the extensions to 8 bits (256 characters)

ISO 8859-x

- Each “language” defines the extended chars
 - » Latin1 (West European) , Latin2 (East European), Latin3 (South European), Latin4 (North European), Cyrillic, Arabic, Greek, Hebrew, Latin5 (Turkish), Latin6 (Nordic)
 - » <http://www.microsoft.com/globaldev/reference/iso.msp>
- How many languages are there?
 - » a gazillion, approximately

Unicode

- Universal character encoding standard
 - » <http://www.unicode.org/>
- 16 bits should cover just about everything ...
 - » “original goal was to use a single 16-bit encoding that provides code points for more than 65,000 characters”
 - » the Java char type is a 16-bit character
- How many characters are needed? ...

Unicode does a million

Table 3-1. UTF-8 Bit Distribution

Scalar Value	UTF-16	1st Byte	2nd Byte	3rd Byte	4th Byte
00000000xxxxxxx	00000000xxxxxxx	0xxxxxxx			
00000yyyyyxxxxxxx	00000yyyyyxxxxxxx	110yyyyy	10xxxxxx		
zzzzyyyyyyxxxxxxx	zzzzyyyyyyxxxxxxx	1110zzzz	10yyyyyy	10xxxxxx	
uuuuuzzzzzyyyyyyxxxxxxx	110110wwwwzzzzyy+ 110111yyyyxxxxxxx	11110uuu ^a	10uuzzzz	10yyyyyy	10xxxxxx

unicode scalar value:

a number N from 0 to $10FFFF_{16}$ ($1,114,111_{10}$)

Some character URLs

- ANSI X3.4 (ASCII)
 - » <http://czyborra.com/charsets/iso646.html>
- ISO 8859 (International extensions)
 - » <http://czyborra.com/charsets/iso8859.html>
- Unicode
 - » <http://www.unicode.org/>
 - » <http://www.unicode.org/iuc/iuc10/x-utf8.html>

czyborra.com seems to be offline right now ...

Moving bytes

- A byte can contain an 8-bit character
- A byte can contain really small numbers
0 to 255_{10} or -128_{10} to 127_{10}
- Sign extension desired effect:
 - » sign bit not extended for characters
 - » sign bit extended for numbers

Loading bytes

- Unsigned: `lbu $reg, a($reg)`
 - » the byte is 0-extended into the register

0000 0000	0000 0000	0000 0000	xxxx xxxx
-----------	-----------	-----------	-----------


- Signed: `lb $reg, a($reg)`
 - » bit 7 is extended through bit 31

0000 0000	0000 0000	0000 0000	0xxx xxxx
-----------	-----------	-----------	-----------

1111 1111	1111 1111	1111 1111	1xxx xxxx
-----------	-----------	-----------	-----------

Storing bytes

- No sign bit considerations
 - » the right most byte in the register is jammed into the byte address given
 - » `sb $t0, 2($sp)`



Storing strings

- Counted strings (for example Pascal strings)
 - » byte `str[0]` holds length: max 255 char
- Counted strings (for example Java strings)
 - » int variable holds length: max 2B char
- Terminated strings (for example C strings)
 - » no length variable, must count: max n/a

strcpy example

```
char *strcpy(char *dst, const char *src) {
    char *s = dst;
    while ((*dst++ = *src++) != '\0')
        ;
    return s;
}
```

Compared to example in the book:

- prototype matches libc
- pointers, not arrays
- better loop

strcpy compiled

strcpy:

```
    move    $v1,$a0           # remember initial dst
loop:
    lbu     $v0,0($a1)        # load a byte
    sb      $v0,0($a0)        # store it
    sll     $v0,$v0,24        # toss the extra bytes
    addu    $a1,$a1,1         # src++
    addu    $a0,$a0,1         # dst++
    bne     $v0,$zero,loop    # loop if not done
    move    $v0,$v1          # return initial dst
    j      $ra                # return
```

Manipulating the bits

- Shift Logical
 - » sll, srl, sllv, srlv - shift bits in word, 0-extend
 - » use these to isolate bits in a word
 - » shift amount in instruction or in register
- Bit by bit
 - » and, andi - clear bits in destination
 - » or, ori - set bits in destination

Shift to the left, shift to the right, push down, pop up, byte, byte, byte!

Example: bit manipulation


```
sll $t1,$t1,24
```

```
0000 0000 0000 0000 0000 1111 1010 1111  
1010 1111 0000 0000 0000 0000 0000 0000
```



```
srl $t1,$t1,28
```

```
1010 1111 0000 0000 0000 0000 0000 0000  
0000 0000 0000 0000 0000 0000 0000 1010
```




```
ori $t1,$t1,0x100
```

```
0000 0000 0000 0000 0000 0000 0000 1010  
0000 0000 0000 0000 0000 0001 0000 1010
```



Example: C bit fields

- Example in the book on page 229 is a typical application of bit fields



- But, note poor choice of field locations
 - » the received byte is not aligned
 - » the byte must be shifted before it can be used
- To: EE designers of interfaces
 - » please consider alignment when selecting fields

Multiply and Divide

- There is a separate integer multiply unit
- Use pseudo-instructions to access

```
mul    $t0, $t1, $t2    # t0 = t1*t2
```

```
div    $t0, $t1, $t2    # t0 = t1/t2
```

- These are relatively slow
 - » multiply 5-12 clock cycles
 - » divide 35-80 clock cycles

Addressing modes

- Register `jr $ra`
- Offset + Register `lw $t0, 0($sp)`
- Immediate `addi $t0, 17`
- PC relative `bnez $t0, loop`
- Pseudodirect `jal proc`

Register only

- Use the 32 bits of the specified register as the desired address
- Can specify anywhere in the program address space, without limitation
- `jr $ra`
 - » return to caller after procedure completes

Offset + Register

- Specify 16-bit signed offset to add to the base register
- Transfer (lw, sw) base register is specified
 - » **lw** **\$t0, 4 (\$sp)**
 - » **sw** **\$t0, 40 (\$gp)**

Immediate

- The 16-bit field holds the constant value

```
0x34080001  ori $8, $0, 1           ; 4: li $t0,1
0x3c01ffff  lui $1, -1                 ; 5: li $t0,-1
0x3428ffff  ori $8, $1, -1
0x3408ffff  ori $8, $0, -1           ; 6: li $t0,0xFFFF
0x3c010001  lui $1, 1                  ; 7: li $t0,0x1FFFFF
0x3428ffff  ori $8, $1, -1
0x3c015555  lui $1, 21845            ; 8: li $t0,0x5555AAAA
0x3428aaaa  ori $8, $1, -21846
0x3c010040  lui $1, 64 [main]    ; 9: la $t0,main
0x34280020  ori $8, $1, 32 [main]
```

PC relative

- Branch (beq, bne) base register is PC
 - » `beq $t0, $t1, skip`
- The 16-bit value stored in the instruction is considered to be a word offset
 - » multiplied by 4 before adding to PC
 - » can branch over ± 32 K instruction range

Pseudodirect

- The specified offset is 26 bits long
 - » Considered to be a word offset
 - » multiplied by 4 before use
- The top 4 bits of the PC are concatenated with the new 28 bit offset to give a 32-bit address
- Can jump within 256 MB segment