

Assembly Programming II

CSE 410 Winter 2017

Instructor:

Justin Hsia

Teaching Assistants:

Kathryn Chan, Kevin Bi, Ryan Wong, Waylon Huang, Xinyu Sui

Administrivia

- ❖ Lab 1 due tomorrow (1/26)
 - You have *late days* available
- ❖ Lab 2 (x86-64) released on Friday (1/27)
- ❖ Homework 2 due next Tuesday (1/31)
- ❖ Optional Section this Thursday
 - Floating Point and GDB (The GNU Debugger)
 - Recommended to bring your laptop
- ❖ Thursday OH moved to 10:30am
 - Kathryn & Xinyu, CSE 2nd floor breakout

x86-64 Introduction

- ❖ Arithmetic operations
- ❖ Memory addressing modes
 - swap example
- ❖ Address computation instruction (lea)

Review: Operand types

❖ *Immediate:* Constant integer data

- Examples: `$0x400`, `$-533`
- Like C literal, but prefixed with '`$`'
- Encoded with 1, 2, 4, or 8 bytes
depending on the instruction

❖ *Register:* 1 of 16 integer registers

- Examples: `%rax`, `%r13`
- But `%rsp` reserved for special use
- Others have special uses for particular instructions

❖ *Memory:* Consecutive bytes of memory at a computed address

- Simplest example: (`%rax`)
- Various other “address modes”

`%rax`

`%rcx`

`%rdx`

`%rbx`

`%rsi`

`%rdi`

`%rsp`

`%rbp`

`%rN`

Some Arithmetic Operations

❖ Binary (two-operand) Instructions:

- Maximum of one memory operand
- Beware argument order!
- No distinction between signed and unsigned
 - Only arithmetic vs. logical shifts
- How do you implement “ $r3 = r1 + r2$ ”?

Format	Computation	
addq <i>src</i> , <i>dst</i>	$dst = dst + src$	($dst += src$)
subq <i>src</i> , <i>dst</i>	$dst = dst - src$	
imulq <i>src</i> , <i>dst</i>	$dst = dst * src$	signed mult
sarq <i>src</i> , <i>dst</i>	$dst = dst >> src$	Arithmetic
shrq <i>src</i> , <i>dst</i>	$dst = dst >> src$	Logical
shlq <i>src</i> , <i>dst</i>	$dst = dst << src$	(same as salq)
xorq <i>src</i> , <i>dst</i>	$dst = dst ^ src$	
andq <i>src</i> , <i>dst</i>	$dst = dst \& src$	
orq <i>src</i> , <i>dst</i>	$dst = dst src$	

↑ operand size specifier

Some Arithmetic Operations

- ❖ Unary (one-operand) Instructions:

Format	Computation	
incq dst	$dst = dst + 1$	increment
decq dst	$dst = dst - 1$	decrement
negq dst	$dst = -dst$	negate
notq dst	$dst = \sim dst$	bitwise complement

- ❖ See CSPP Section 3.5.5 for more instructions:
`mulq`, `cqto`, `idivq`, `divq`

Arithmetic Example

```
long simple_arith(long x, long y)
{
    long t1 = x + y;
    long t2 = t1 * 3;
    return t2;
}
```

Register	Use(s)
%rdi	1 st argument (x)
%rsi	2 nd argument (y)
%rax	return value

```
y += x;
y *= 3;
long r = y;
return r;
```

```
simple_arith:
    addq    %rdi, %rsi
    imulq   $3, %rsi
    movq    %rsi, %rax
    ret
```

Example of Basic Addressing Modes


```
void swap(long *xp, long *yp)
{
    long t0 = *xp;
    long t1 = *yp;
    *xp = t1;
    *yp = t0;
}
```

```
swap:
    movq (%rdi), %rax
    movq (%rsi), %rdx
    movq %rdx, (%rdi)
    movq %rax, (%rsi)
    ret
```

Understanding swap()


```
void swap(long *xp, long *yp)
{
    long t0 = *xp;
    long t1 = *yp;
    *xp = t1;
    *yp = t0;
}
```

```
swap:
    movq (%rdi), %rax
    movq (%rsi), %rdx
    movq %rdx, (%rdi)
    movq %rax, (%rsi)
    ret
```



<u>Register</u>	<u>Variable</u>
%rdi	\Leftrightarrow xp
%rsi	\Leftrightarrow yp
%rax	\Leftrightarrow t0
%rdx	\Leftrightarrow t1


Understanding swap()



swap:

```
    movq (%rdi), %rax    # t0 = *xp
    movq (%rsi), %rdx    # t1 = *yp
    movq %rdx, (%rdi)    # *xp = t1
    movq %rax, (%rsi)    # *yp = t0
    ret
```


Understanding swap()



swap:

```
movq (%rdi), %rax    # t0 = *xp
movq (%rsi), %rdx    # t1 = *yp
movq %rdx, (%rdi)    # *xp = t1
movq %rax, (%rsi)    # *yp = t0
ret
```


Understanding swap()



```
swap:
```

```
    movq (%rdi), %rax    # t0 = *xp
    movq (%rsi), %rdx    # t1 = *yp
    movq %rdx, (%rdi)    # *xp = t1
    movq %rax, (%rsi)    # *yp = t0
    ret
```


Understanding swap()



swap:

```
    movq (%rdi), %rax    # t0 = *xp
    movq (%rsi), %rdx    # t1 = *yp
    movq %rdx, (%rdi)    # *xp = t1
    movq %rax, (%rsi)    # *yp = t0
    ret
```

Understanding swap()



```
swap:
```

```
    movq (%rdi), %rax    # t0 = *xp
    movq (%rsi), %rdx    # t1 = *yp
    movq %rdx, (%rdi)    # *xp = t1
    movq %rax, (%rsi)    # *yp = t0
    ret
```

Memory Addressing Modes: Basic

❖ **Indirect:** (R) Mem[Reg[R]]

- Data in register R specifies the memory address
- Like pointer dereference in C
- Example: `movq (%rcx), %rax`

❖ **Displacement:** D(R) Mem[Reg[R]+D]

- Data in register R specifies the *start* of some memory region
- Constant displacement D specifies the offset from that address
- Example: `movq 8(%rbp), %rdx`

Complete Memory Addressing Modes

❖ General:

- $D(Rb, Ri, S) \quad \text{Mem}[Reg[Rb]+Reg[Ri]*S+D]$
 - Rb: Base register (any register)
 - Ri: Index register (any register except %rsp)
 - S: Scale factor (1, 2, 4, 8) – *why these numbers?*
 - D: Constant displacement value (a.k.a. immediate)

❖ Special cases (see CSPP Figure 3.3 on p.181)

- $D(Rb, Ri) \quad \text{Mem}[Reg[Rb]+Reg[Ri]+D] \quad (S=1)$
- $(Rb, Ri, S) \quad \text{Mem}[Reg[Rb]+Reg[Ri]*S] \quad (D=0)$
- $(Rb, Ri) \quad \text{Mem}[Reg[Rb]+Reg[Ri]] \quad (S=1, D=0)$
- $(, Ri, S) \quad \text{Mem}[Reg[Ri]*S] \quad (Rb=0, D=0)$

Address Computation Examples

%rdx	0xf000
%rcx	0x0100

$D(Rb, Ri, S) \rightarrow$
 $\text{Mem}[\text{Reg}[Rb] + \text{Reg}[Ri] * S + D]$

Expression	Address Computation	Address
0x8(%rdx)		
(%rdx,%rcx)		
(%rdx,%rcx,4)		
0x80(,%rdx,2)		

Address Computation Instruction

- ❖ `leaq src, dst`
 - “`lea`” stands for *load effective address*
 - `src` is address expression (any of the formats we’ve seen)
 - `dst` is a register
 - Sets `dst` to the *address* computed by the `src` expression
(does not go to memory! – it just does math)
 - Example: `leaq (%rdx,%rcx,4), %rax`
- ❖ Uses:
 - Computing addresses without a memory reference
 - e.g. translation of `p = &x[i];`
 - Computing arithmetic expressions of the form `x+k*i+d`
 - Though `k` can only be 1, 2, 4, or 8

Example: lea vs. mov

Registers

%rax	
%rbx	
%rcx	0x4
%rdx	0x100
%rdi	
%rsi	

Memory

0x400
0xF
0x8
0x10
0x1

Word Address

0x120
0x118
0x110
0x108
0x100

```
leaq (%rdx,%rcx,4), %rax
movq (%rdx,%rcx,4), %rbx
leaq (%rdx), %rdi
movq (%rdx), %rsi
```

Arithmetic Example

```
long arith(long x, long y, long z)
{
    long t1 = x + y;
    long t2 = z + t1;
    long t3 = x + 4;
    long t4 = y * 48;
    long t5 = t3 + t4;
    long rval = t2 * t5;
    return rval;
}
```

Register	Use(s)
%rdi	1 st argument (x)
%rsi	2 nd argument (y)
%rdx	3 rd argument (z)

```
arith:
leaq    (%rdi,%rsi), %rax
addq    %rdx, %rax
leaq    (%rsi,%rsi,2), %rdx
salq    $4, %rdx
leaq    4(%rdi,%rdx), %rcx
imulq   %rcx, %rax
ret
```

- ❖ Interesting Instructions
 - leaq: “address” computation
 - salq: shift
 - imulq: multiplication
 - Only used once!

Arithmetic Example

```
long arith(long x, long y, long z)
{
    long t1 = x + y;
    long t2 = z + t1;
    long t3 = x + 4;
    long t4 = y * 48;
    long t5 = t3 + t4;
    long rval = t2 * t5;
    return rval;
}
```

Register	Use(s)
%rdi	x
%rsi	y
%rdx	z, t4
%rax	t1, t2, rval
%rcx	t5

```
arith:
leaq    (%rdi,%rsi), %rax      # rax/t1      = x + y
addq    %rdx, %rax            # rax/t2      = t1 + z
leaq    (%rsi,%rsi,2), %rdx   # rdx          = 3 * y
salq    $4, %rdx              # rdx/t4      = (3*y) * 16
leaq    4(%rdi,%rdx), %rcx   # rcx/t5      = x + t4 + 4
imulq   %rcx, %rax            # rax/rval    = t5 * t2
ret
```

Peer Instruction Question

- ❖ Which of the following x86-64 instructions correctly calculates $\%rax = 9 * \%rdi$?
 - Vote at <http://PollEv.com/justinh>

- A. **leaq (,%rdi,9), %rax**
- B. **movq (,%rdi,9), %rax**
- C. **leaq (%rdi,%rdi,8), %rax**
- D. **movq (%rdi,%rdi,8), %rax**
- E. **We're lost...**

x86 Control Flow

- ❖ Condition codes
- ❖ Conditional and unconditional branches
- ❖ Loops
- ❖ Switches

Control Flow

```
long max(long x, long y)
{
    long max;
    if (x > y) {
        max = x;
    } else {
        max = y;
    }
    return max;
}
```

Register	Use(s)
%rdi	1 st argument (x)
%rsi	2 nd argument (y)
%rax	return value

```
max:
???
movq    %rdi, %rax
???
???
movq    %rsi, %rax
???
ret
```

Control Flow

```
long max(long x, long y)
{
    long max;
    if (x > y) {
        max = x;
    } else {
        max = y;
    }
    return max;
}
```

Conditional jump
Unconditional jump

```
max:
if x <= y then jump to else
    movq    %rdi, %rax
    jump to done
else:
    movq    %rsi, %rax
done:
    ret
```

Register	Use(s)
%rdi	1 st argument (x)
%rsi	2 nd argument (y)
%rax	return value

Conditionals and Control Flow

- ❖ Conditional branch/jump
 - Jump to somewhere else if some *condition* is true, otherwise execute next instruction
- ❖ Unconditional branch/jump
 - Always jump when you get to this instruction
- ❖ Together, they can implement most control flow constructs in high-level languages:
 - **if** (*condition*) **then** { ... } **else** { ... }
 - **while** (*condition*) { ... }
 - **do** { ... } **while** (*condition*)
 - **for** (*initialization*; *condition*; *iterative*) { ... }
 - **switch** { ... }

Summary

- ❖ **Memory Addressing Modes:** The addresses used for accessing memory in mov (and other) instructions can be computed in several different ways
 - *Base register, index register, scale factor, and displacement* map well to pointer arithmetic operations
- ❖ lea is address calculation instruction
 - Does NOT actually go to memory
 - Used to compute addresses or some arithmetic expressions
- ❖ Control flow in x86 determined by status of Condition Codes