

# CSE 550: *Systems for all*

Au 2021

Ratul Mahajan

# Transport protocol challenges

## Flow control

- Do not send faster than the receiver's consumption capacity

## Congestion control

- Do not send faster than the networks delivery capacity

# Congestion control challenges

Network capacity is unknown

- Individual links can vary from less than 100 Kbps to more than 100 Gbps

Network capacity varies with time

- E.g., distance from cellular base stations or WiFi access points

Network capacity is shared

- Don't know how many other users are there and their needs

What if you send too slow?


What if you send too fast?

# Congestion Collapse in the 1980s

- Early TCP used fixed size window (e.g., 8 packets)
  - Initially fine for reliability
- But something happened as the network grew
  - Links stayed busy but transfer rates fell by orders of magnitude!


# Nature of Congestion

- Routers/switches have internal buffering



# Nature of Congestion (2)

- Simplified view of per port output queues
  - Typically FIFO (First In First Out), discard when full





# Nature of Congestion (3)



Queues help by absorbing bursts when  $\text{input} > \text{output rate}$

But if  $\text{input} > \text{output rate}$  persistently, queue will overflow

This is congestion

Congestion is a function of the traffic patterns – can occur even if every link has the same capacity

# Effects of Congestion



# Effects of Congestion (2)

As offered load rises, congestion occurs as queues begin to fill:

Delay and loss rise sharply with load

Throughput  $<$  load (due to loss)

Goodput  $\ll$  throughput (due to spurious retransmissions)

None of the above is good!

Want network performance just before congestion



# Congestion control design space: Congestion indicator

Several possible signals, with different pros/cons

Signal	Example Protocol	Pros / Cons
Packet loss	TCP Cubic TCP (Linux)	Hard to get wrong Hear about congestion late Other events can cause loss
Packet delay	BBR (Google)	Hear about congestion early Need to infer congestion
Router indication	ECN, DCTCP	Hear about congestion early Requires router support

# Congestion control design space: Control mechanism

Two main controls, but hybrids also possible

Control	Example Protocol	Pros/Cons
Window based	TCP Cubic TCP (Linux) DCTCP	Self-clocking Can be Jittery
Rate based	BBR (Google)	Smoother Tricky estimation

Over to Diya and Peter